



# Understanding molecular SO<sub>2</sub> calculators

A previous Ask the AWRI column (January, 2017) described the importance of molecular SO<sub>2</sub> and how to calculate it. This column responds to recent questions received by the AWRI helpdesk about the different online molecular SO<sub>2</sub> calculators available and why they can give different results.



Sulfur dioxide is converted to three different forms when added to wine.

## What are the different forms of SO<sub>2</sub>?

Sulfur dioxide (SO<sub>2</sub>) exists as a gas but when added to wine it converts to three different forms: molecular (SO<sub>2</sub>), bisulfite (HSO<sub>3</sub><sup>-</sup>) and sulfite (SO<sub>3</sub><sup>2-</sup>). All three forms exist in wine in an equilibrium, as shown in Figure 1.

The amount of each form of SO<sub>2</sub> in a juice or wine is dependent on the wine pH. Ka<sub>1</sub> and Ka<sub>2</sub> are 'dissociation constants' and represent the pH values at which the two forms of SO<sub>2</sub> involved in the equilibria exist in equal amounts. For the pH range 3.0 to 4.0 (shaded in purple), the molecular SO<sub>2</sub> (mSO<sub>2</sub>) declines from ~8% to 1% and the bisulfite ion increases from 92 to 99%. As only 0.02 to 0.04% of the SO<sub>2</sub> exists in the sulfite (SO<sub>3</sub><sup>2-</sup>) form at wine pH, the mSO<sub>2</sub> calculation is based solely on the first equilibrium (SO<sub>2</sub> ⇌ HSO<sub>3</sub><sup>-</sup>), so only the Ka<sub>1</sub> value is used.

## Why do I get different values for mSO<sub>2</sub> depending on the website/calculator that I use?

The relationship between molecular and free SO<sub>2</sub> is given by the equation:

Molecular SO<sub>2</sub> = free SO<sub>2</sub> / (1 + 10<sup>pH-pKa<sub>1</sub></sup>), where pKa<sub>1</sub> = -log<sub>10</sub>Ka<sub>1</sub>

This means that if the free SO<sub>2</sub>, the pH and Ka<sub>1</sub> are known, mSO<sub>2</sub> can be calculated. The differences observed for mSO<sub>2</sub> values from different calculators is due to the use of different values for Ka<sub>1</sub> (and hence pKa<sub>1</sub>) in the formula.

## What's the importance of pKa<sub>1</sub> and why are different values used?

Apart from pH, several other wine parameters influence the amount of SO<sub>2</sub> in the molecular form. Temperature, alcoholic strength and ionic strength (a measure of the concentration of all the ions in solution) all affect the value of pKa<sub>1</sub> and consequently the level of mSO<sub>2</sub>. The effects of these parameters on mSO<sub>2</sub> are summarised in Table 1.

As ionic strength is not something most wineries can easily determine, a value of 0.038M is commonly used in online calculators. This value is the approximate midpoint of the ionic strength range of 0.016 to 0.056M reported for wines (Delfini and Formica 2001).

The effect of temperature and alcohol on the concentration of mSO<sub>2</sub> are much greater than that of ionic strength. Using the ionic strength value above (or similar value), some online

calculators allow users to input alcohol and temperature measurements. Such calculators may provide a more accurate estimation of the mSO<sub>2</sub>.

The AWRI's mSO<sub>2</sub> calculator (available on the AWRI winemaking calculators webpage and app) uses a value of 1.81 for the value of pK<sub>a1</sub>, which is the value for SO<sub>2</sub> in water at 25°C. The use of this value is somewhat historical in that it's the value that was used by early wine authors to calculate levels of mSO<sub>2</sub> recommended to control microorganisms in wine. For example, Beech et al. (1979) used this value to calculate the mSO<sub>2</sub> concentration range (0.54 to 0.9 mg/L) recommended to restrict the growth of *Saccharomyces cerevisiae* yeast. This same value for pK<sub>a1</sub> was used by AWRI researchers when recommending mSO<sub>2</sub> concentrations above 0.625 mg/L to inhibit the growth of *Brettanomyces* in red wines (Curtin et al. 2012). Given the same pK<sub>a1</sub> value has been used by the AWRI to calculate mSO<sub>2</sub> for many years, current mSO<sub>2</sub> values obtained using the AWRI's calculator can be directly related to historical values. This can be useful, for example, if a winemaker found that a level of mSO<sub>2</sub> for a particular wine style was insufficient in the past and therefore needed to be increased. Such comparisons with historical values would not possible if the AWRI updated its calculator to consider variations in alcoholic strength and temperature.

‘ Apart from pH, several other wine parameters influence the amount of SO<sub>2</sub> in the molecular form

Molecular SO<sub>2</sub> calculators that incorporate alcoholic strength and temperature are likely to return higher values for mSO<sub>2</sub> than the AWRI calculator, which is likely to give an underestimation of the ‘true’ level of mSO<sub>2</sub>. It should also be noted that SO<sub>2</sub> is typically measured at around 20–22°C, so mSO<sub>2</sub> values calculated based on a free SO<sub>2</sub> result in this temperature range will be an overestimation of the true concentration of mSO<sub>2</sub> if the bulk wine is actually stored at a lower temperature.

For further information on molecular SO<sub>2</sub> or any other grapegrowing and winemaking technical matters, contact the AWRI helpdesk on [helpdesk@awri.com.au](mailto:helpdesk@awri.com.au) or 08 8313 6600.

Table 1. Effect of increasing temperature, alcoholic strength and ionic strength on pK<sub>a</sub>, and the concentration of mSO<sub>2</sub>

Parameter	Effect on pK <sub>a1</sub>	Effect on mSO <sub>2</sub> concentration
↑ Temperature	↑	↑
↑ Alcoholic strength	↑	↑
↑ Ionic strength	↓	↓




Figure 1. Different forms of sulfur dioxide (SO<sub>2</sub>) as a function of pH in dilute solution



### References

Beech, F.W., Burroughs, L.F., Timberlake, C.F., Whiting, G.C. 1979. Progrès récents sur l'aspect chimique et l'action antimicrobienne de l'anhydride sulfureux (SO<sub>2</sub>). Bulletin de l'OIV. 52 (586): 1001-1022.

Curtin, C., Kennedy, E., Henschke, P. A. 2012. Genotype-dependent sulphite tolerance of Australian *Dekkera* (*Brettanomyces*) *bruxellensis* wine isolates. Lett. Appl. Microbiol. 55(1), 56-61.

Delfini, C. Formica, J.V. 2001. Wine microbiology: science and technology. New York: CRC Press.


GW

# ORIGINAL

## fine grain barrels

Since the beginning, Saury has operated on the basis that grain is the most important determinant of barrel quality. Today, the cooperage still applies this theory to each and every barrel, growing into a modern, efficient and quality focused cooperage while maintaining its status as a maker of the finest grain oak barrels in the world.



**For further information, please contact Kauri**

AUS Tel: 1800 127 611      NZ Tel: 0800 KAURIWINE  
Email: [info@kauriwine.com](mailto:info@kauriwine.com)      Website: [www.kauriwine.com](http://www.kauriwine.com)